



Printed in EU

# Speedboat Playset



SCOOBY & SHARK FIGURES




# SCOOBY-DOO!



**WARNING: CHOKING HAZARD-**  
Toy contains small parts.  
Not for children under 3 years.

1




x1




x1



x2



2



x2



x1



x2

3



x1



x1



x2



x1

4



x1




x1



x2



x1



5




x1



x1



x1




6




x2



x2



7



x2



x2

8



x1


x1

x1


x1

x1

x1



- 1.  x1
- 2.  x1
- 3.  x4
- 4.  x2
- 5.  x1
- 6.  x2
- 7.  x1
- 8.  x1
- 9.  x2
- 10.  x1
- 11.  x1
- 12.  x1
- 13.  x1
- 14.  x1
- 15.  x1
- 16.  x2
- 17.  x2
- 18.  x2
- 19.  x2
- 20.  x1
- 21.  x1
- 22.  x1
- 23.  x1
- 24.  x1
- 25.  x2
- 26.  x1
- 27.  x1



TM & © Hanna-Barbera  
WB Shield: TM & © Warner Bros. Entertainment, Inc.  
(s13)

05-23080-38